




Headquarters:
1776 Massachusetts Ave., N.W., Suite 500
Washington, DC 20036
202/659-3537

STEP • BY • STEP METHOD FOR INSTALLING YOUR OWN


CHAIN LINK FENCE

HOMES
YARDS
SWIMMING POOLS

HINTS FOR ERECTING CHAIN LINK FENCE




A Even grade between terminal posts



B Level grade




C Fence following grade



D Level grade with rolling terrain


Next, stretch a masons line from outside of terminal posts to outside of terminal posts (be sure the concrete has set up sufficiently so as not to lose plumb). The line post holes should be lined up so that when they are set in the center of their holes, their centers will line up with the terminal post centers. This means the outside faces of the line posts will be about 1/4" inside of the line stretched between the outside of the terminal posts. Now dig the line post holes and set the line posts.



Next, stretch your masons line taut four inches below terminal post tops and use as a guide to align height of line posts (see Figure 4 above). If necessary to adjust height of any post either up or down, simply raise or lower post as illustrated before concrete sets up. Use your level to keep plumb while adjusting post height.


STEP 4 - APPLY FITTINGS TO TERMINAL POSTS

Check material list and fittings identification chart. After the posts have been installed and the concrete allowed to set, slip tension and brace bands on terminal posts. (See Figure 5.) The tension bands should be spaced approximately 10-12" apart. Do not spread or distort bands. All bolt heads for bands are on the outside of fence and the threaded ends are on the inside. Then apply all terminal post caps.





STEP 5 - APPLY TOP RAIL

Next, attach loop caps. (See Figure 6.) They are set with the top rail hole offset toward the outside of the fence making flush the outside face of the top rail through the loop caps. (See Figure 7.) Join the top rail with swedged end where required. (See Figure 8.) End of the top rail fits into rail end fittings on the terminal post. (See Figure 9.)



STEP 6 - HANG FABRIC

After assembling the framework, unroll the fabric on the ground along the fence line starting at a terminal post. Then slide tension bar thru the last link in your fabric and attach this combination to the terminal post using tension band and bolts provided. (See Figure 10.) If more or less fabric is needed to span the opening, an additional amount can be connected or removed as shown in Figure 11. The fabric should be on the outside face of all posts and loosely attached to the top rail by a tie wire.



STEP 7 - STRETCH FABRIC

Fabric should be stretched from the terminal post already attached to the opposite terminal post. Insert tension bar in end of fabric and attach fence stretcher to bar (ratchet type power pull, large carpenter's clamps, block and tackle, or similar device may be used. Most wire stretching tools of this type can be rented or borrowed locally.)

As you stretch the fabric test it for tension (it is stretched enough when it gives slightly). The top of the fabric should be located approximately 1/2" above the top rail to insure proper height. After fence fabric is sufficiently tight, remove the excess fabric as shown in Figure 11, and connect the tension bar to the post with tension bands. Also fasten the fabric to the top rail and line posts with tie wires spaced approximately 18" apart.






Figure 13



3' WALK GATE











10' DOUBLE DRIVE GATE

STEP 8 – HANG GATES

After the entire fence has been completed, apply male hinges to one of the gate posts, hanging the top hinge upside down thus preventing the gate from being lifted off. Loosely apply female hinges on the gate frame and slip them onto the male hinges that have been installed on the gate post. Set hinges to allow for full swing of the gate and align the top of the gate with the top of the fence. Tighten all hinges securely. Install gate latch for single gates. For double gates, use the same procedure as on walk gates but install center latching device (fork latch).

MATERIALS NEEDED FOR RESIDENTIAL CHAIN LINK FENCE

PIECES	ITEM—DESCRIPTION	QUANTITY TO USE
(1)	 Fabric (50 feet per roll)	Divide total footage by 50 and round up
(2)	 Top Rail Swaged End 1 3/8" or 1 5/8" O.D.	Total footage
(3)	 Line Post 1 5/8" or 2" O.D.	Divide total footage by 10 and round up
(4)	 Loop Caps match to post and rail	Use 1 per line post
(5)	 Terminal Post 2" or 2 1/2" O.D.	—
(6)	 Tension Bar	Use 1 per end or gate post, 2 per corner post
(7)	 Brace Band	Use 1 per tension bar
(8)	 Rail Ends	Use 1 per tension bar
(9)	 Tension Band	Use 4 per tension bar or 1' per foot of fence height
(10)	 5/16" x 1 1/4" Carriage Bolts	Use 1 per tension or brace band
(11)	 Terminal Post Caps	Use 1 per terminal post
(12)	 Alum Hook Ties	Use 1 per foot of fence— Packaged 100 per bag
(13)	 Walk Gate (3' or 3 1/2' wide)	—
(14)	 Double Drive Gate (10' or 12' wide)	—
(15)	 Male Hinge	Use 2 per walk gate and 4 per double drive gate
(16)	 3/8" x 3" Carriage Bolts	Used with the male hinge, 1 per hinge
(17)	 Female Hinge 1 3/8"	Use 2 per walk gate and 4 per double drive gate
(18)	 3/8" x 1 3/4" Carriage Bolts	Used with female hinge, 1 per hinge
(19)	 Fork Latch	Needed on walk gates only—1 per gate

TOOLS YOU WILL FIND USEFUL IN INSTALLING YOUR FENCE

- | | |
|--|--|
| 1. Post Hole Digger | 6. Pliers |
| 2. Wheelbarrow, Shovel and Hoe to mix and transport concrete | 7. Fence Stretcher (Block and tackle, ratchet type power pull, etc.) |
| 3. Tape Measure | 8. 1/2" X 9/16" Wrench or Crescent Wrench |
| 4. Level | 9. Hacksaw or Pipe Cutter |
| 5. String and Stakes or Mason's Line | |